



Keep the area sanitized.
Wash hands (or gloves) every time you handle the kit.
These kits do not need hydration for the first flush.
Ideal storage between 4 and 6 degrees Celsius. Maximum of 6 weeks.

Contents

- 1200 ml container
- Grow bag
- Instruction manual
- Small bag of casing substrate

Required materials

- Water
- Gloves
- Mask
- Grow bag or plastic propagator
- Sprayer
- Alcohol

WITH GROW BAG

1. Thoroughly clean the working area with alcohol.
2. Remove the lid and save it.
3. Open the casing bag and spread it over the surface of the container, creating a thin layer.
4. It is recommended to add a small amount of water inside the bag.
5. Place the kit inside the grow bag.
6. Spray the inside walls of the bag with tap water and close the zipper halfway (half open, half closed).*
7. Spray the inside of the bag once a day (or twice if needed).
8. When primordia appear, open the zipper 2/3 of the way.
9. Ventilate twice a day for 10 minutes, and spray the inside walls before closing the bag again.
10. Harvest 5-6 hours after the veil breaks.
11. Grasp the base of the mushroom, twist slightly, and carefully pull it out. Otherwise, you might damage the surface and delay future flushes.
12. Once all mushrooms are harvested, remove the kit from the bag and fill it with tap water.
13. Close the kit with the lid and let it soak for 20 minutes at room temperature.
14. Drain the excess water and repeat the previous steps.

* **Tip:** If the inside of the bag is too dry, close the zipper more. If it's too moist, open it a bit more.

WITH PLASTIC PROPAGATOR

1. Thoroughly clean the working area and the mini greenhouse with isopropyl alcohol.
2. Add 2 cm of tap water to the bottom of the propagator.
3. Remove the kit's lid and spread the casing substrate over the surface of the kit.
4. Place the kit inside the propagator with the air vents open.
5. If there is excess humidity when primordia appear, open the propagator lid once a day.
6. For harvesting and rehydrating the kit, follow steps 10-14 from the grow bag instructions.